

QuickShifter easy Supplementary Manual



KTM SX 85 2010-2017 (iQSE-2 + QSH-CKP)

Secure the bike on a stand.



Remove the seat.

Remove the side fairings and the fuel tank.



Connect the two QSH Green wires to the White/Red and the White/Blue wires of the ignition pulse generator.



QuickShifter easy Supplementary Manual



KTM SX 85 2010-2017 (iQSE-2 + QSH-CKP)

Connect the QSH Red wire to the battery positive terminal via an on/off switch.

Connect the QSH Black wire to the battery negative terminal.

(We recommend using a 12V gel-type battery with 1.3Ah capacity or smaller.)



Mount the QSE sensor.

Make sure that there is at least 3 mm between the screw head and the chain.

(Replace the bolt with the one supplied. Place the supplied washers at both sides of the sensor. Tighten the bolt in this position by about 6 Nm. If you do not have torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)



Typical position for the QuickShifter easy.

Secure the unit properly.

