

# QuickShifter easy Supplementary Manual



## SWM RS500R ABS 2015-2019 (iQSE-W1 + QSH-F2A)

Secure the bike on a stand.



Remove the seat and the side fairings.

Remove the fuel tank.



Locate the fuel injector connectors under the fuel tank.

Plug the QSH connectors in-line with the fuel injector connectors.

*(Make sure the QSH plugs marked with RED square are connected, and leave the other one coupler unused)*





# QuickShifter easy Supplementary Manual



## SWM RS500R ABS 2015-2019 (iQSE-W1 + QSH-F2A)

Connect the QSH Black wire terminal to the battery negative terminal.



Mount the QSE sensor.

*(Replace the bolt with the one supplied. Place the supplied washers at both sides of the sensor. Tighten the bolt in this position by about 6 Nm. If you do not have torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

