


QuickShifter easy Supplementary Manual

BMW R1150 GS 1999-2005 (iQSE-1 + QSH-F2D)

Remove the main seat.



Lift up or remove the fuel tank.



Plug the QSH connectors in-line with the
fuel injector connectors.

(Black, 2-pole connectors)



QuickShifter easy Supplementary Manual



BMW R1150 GS 1999-2005 (iQSE-1 + QSH-F2D)

Connect the QSH Black wire terminal to the battery negative terminal.



Mount the QSE sensor.

*(Replace the bolt with the one supplied.
Place the supplied washers at both sides of the sensor. Tighten the bolt in this position by about 6 Nm. If you do not have torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

