

# QuickShifter easy Supplementary Manual

## BMW R1250R ABS TC 2019- (iQSE-W1 + QSX-F2L)

Secure the bike on a stand.



Remove the seat.

Remove the covers from the injector connectors.



Locate the fuel injector connectors.

Plug the QSX connectors in-line with the fuel injector connectors.



# QuickShifter easy Supplementary Manual



## BMW R1250R ABS TC 2019- (iQSE-W1 + QSX-F2L)

Connect the QSX Black wire terminal to the battery negative terminal.



Mount the QSE sensor.

*(Place the sensor in the rod as shown.  
Tighten the nut by hand fully and then by a  
1/4 turn using a wrench but maximum to  
about 6 Nm.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

