

Yamaha XJ6N 2009-2015 (TB-U02)

Secure the bike on a stand.



Remove the seat and the cover from the battery.



Connect the TB terminals directly to the battery terminals.

Connect your accessories to the TB output terminal blocks.



Yamaha XJ6N 2009-2015 (TB-U02)

Optional:

If you wish to connect the White wire, splice it at the brake light switch connector to the Yellow wire.



Typical position for the ThunderBox.

Secure the unit properly.

