

# Oxygen Sensor Eliminator Supplementary Manual

SWM RS500R 2015-2019 (OSE-08)

Secure the bike on a stand.



Remove the seat and the side covers.

Remove the fuel tank.



Locate the oxygen sensor connector  
under the fuel tank.

*(Transparent, 4-pole connector)*



# Oxygen Sensor Eliminator Supplementary Manual



SWM RS500R 2015-2019 (OSE-08)

Unplug the oxygen sensor connector.

Plug the OSE connector into the wiring harness connector.

Secure the unit properly.

