

# QuickShifter easy Supplementary Manual



## Yamaha YZF-R6 2003-2005 (iQSE-1 + QSH-F4B)

Remove the passenger seat.

Remove the main seat.



Lift up or remove the fuel tank.



Plug the QSH connectors in-line with the  
fuel injector connectors.

*(Gray, 2-pole connectors below the airbox)*




# QuickShifter easy Supplementary Manual



## Yamaha YZF-R6 2003-2005 (iQSE-1 + QSH-F4B)

Connect the QSH Black wire terminal to the chassis ground.



Mount the QSE sensor.

*(Replace the bolt with the one supplied. Place the supplied washers at both sides of the sensor. Tighten the bolt in this position by about 6 Nm. If you do not have torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

