

Aprilia RSV Mille 2004-2011 (iQSE-1 + QSH-P1A)

Remove the main seat.



Lift up or remove the fuel tank.



Locate the ignition coil connector on the
right side below the fuel tank.

(Black, 3-pole connectors)




QuickShifter easy Supplementary Manual



Aprilia RSV Mille 2004-2011 (iQSE-1 + QSH-P1A)

Connect the QSH connectors in-line with the ignition coil connectors.




Connect the QSH Black wire terminal to the battery negative terminal.



Mount the QSE sensor.

*(Replace the bolt with the one supplied.
Place the supplied washers at both sides of
the sensor. Tighten the bolt in this position
by about 6 Nm. If you do not have torque
wrench, tighten the bolt until the shift arm
is tight on the gearbox shaft.)*



QuickShifter easy Supplementary Manual



Aprilia RSV Mille 2004-2011 (iQSE-1 + QSH-P1A)

Typical position for the QuickShifter easy.

Secure the unit properly.

