

QuickShifter easy Supplementary Manual



Yamaha FZ-1 2006-2017 (iQSE-1 + QSH-P4A)

Remove the seats.

Remove or lift up the fuel tank.

Remove the radiator cover side panels.



Plug the QSH connectors in-line with the ignition coil connectors.



Connect the QSH Black wire terminal to the chassis ground.



QuickShifter easy Supplementary Manual



Yamaha FZ-1 2006-2017 (iQSE-1 + QSH-P4A)

Mount the QSE sensor.

*(Replace the bolt with the one supplied.
Place the supplied washers at both sides of
the sensor. Tighten the bolt in this position
by about 6 Nm. If you do not have torque
wrench, tighten the bolt until the shift arm
is tight on the gearbox shaft.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

