


QuickShifter easy Supplementary Manual

Aprilia RSV4 2009-2016 (iQSE-1 + QSH-P4F)

Remove the seats.



Remove the frame covers below the fuel tank.



Lift up or remove the fuel tank.



QuickShifter easy Supplementary Manual

Aprilia RSV4 2009-2016 (iQSE-1 + QSH-P4F)

Connect the QSH connectors in-line with the ignition coil connectors on left side.

(Black, 3-pole connectors on the front cylinders)



Connect the QSH connectors in-line with the ignition coil connectors on right side.

(Black, 3-pole connectors on the front cylinders)



Connect the QSH connectors in-line with the ignition coil connectors on the airbox.

(Black, 3-pole connectors from the rear cylinders)



QuickShifter easy Supplementary Manual



Aprilia RSV4 2009-2016 (iQSE-1 + QSH-P4F)

Mount the QSE sensor.

*(Replace the bolt with the one supplied.
Place the supplied washers at both sides of
the sensor. Tighten the bolt in this position
by about 6 Nm. If you do not have torque
wrench, tighten the bolt until the shift arm
is tight on the gearbox shaft.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

