


QuickShifter easy Supplementary Manual

Suzuki GSX-R600 2008-2009 (iQSE-1 + QSX-P4B)

Remove the seats.


Remove the rear fairing from left side.



Remove the fuel tank.



Remove the airbox.



QuickShifter easy Supplementary Manual



Suzuki GSX-R600 2008-2009 (iQSE-1 + QSX-P4B)

Plug the QSX connectors in-line with the ignition coil connectors.

(Black, 2-pole connectors below the airbox)



Mount the QSX module to the inner side of the frame by the supplied Velcro strips, and secure the cables with cable ties.

(Avoid direct contact with heat sources, like the cylinder head.)



Connect the QSX Black wire terminal to the chassis ground.



QuickShifter easy Supplementary Manual



Suzuki GSX-R600 2008-2009 (iQSE-1 + QSE-P4B)

Mount the QSE sensor.

(Place the sensor in the rod as shown. Use the washers supplied at both sides of the sensor. Tighten the nut by hand fully and then by a 1/4 turn using a wrench but maximum to about 6 Nm.)



Typical position for the QuickShifter easy.

Secure the unit properly.

