

STV Eliminator Supplementary Manual



Kawasaki W800 2011- (STVE-07)


Locate the throttle body assembly under the fuel tank.

Find the two connectors of the actuator motor and the STPS (secondary throttle position sensor) on the throttle body assembly.



Unplug the two connectors.

Remove the butterfly valve flaps/throttle plates.



Plug the STVE module into the wiring harness connectors.



STV Eliminator Supplementary Manual



Kawasaki W800 2011- (STVE-07)

Typical position for the STVE.

Secure the unit properly.

